



# Swimkleen Pool Cleaner Diaphragm Installation

## Removing Old Diaphragm (Step 1 - 4)



**Step 1** Turn extension housing & nut anticlockwise to loosen and remove.



**Step 2** Remove inner extension pipe from diaphragm.



**Step 3** Squeeze top edge section of diaphragm together and push down.



**Step 4** Remove diaphragm from Swimkleen body.

## Installing New Diaphragm (Step 5 - 12)



**Step 5**  
Squeeze top edge section of diaphragm in half as in diaphragm A.



Insert folded top edge of diaphragm into inner extension pipe as in diaphragm B.



**Step 6** Turn cleaner body upside down insert inner tube with diaphragm and pull through cleaner body until the diaphragm pops in and releases from inner extension pipe.



**Step 7** Ensure diaphragm and retaining ring is correctly seated into cleaner body.



**Step 8** Ensure the top end of diaphragm is correctly positioned in top end of cleaner.



**Step 9** Once diaphragm is correctly positioned push out folded end to fully open diaphragm tube.



**Step 10** Insert inner tube and ensure correct engagement with diaphragm.



**Step 11** Re-install deflector ring onto cleaner body, outer extension housing & nut, tightening nut clockwise.



**Step 12** Re-connect cleaner suction hose and your Swimkleen Pool Cleaner is ready to go back to work keeping your pool clear of debris.